

Curtain calculator

Enter rod height and width in inches; choose fullness (1.5–2.5) and the allowance below the floor (+) or above (–).

Window	Rod height (in)	Finish offset (in)	Drop needed (in)	Rod width (in)	Fullness	Total fabric width (in)	Panels (if 50 in wide)
Living room	89	-0.5	88.5	64	2	128	3
Bedroom	84	4	88	50	2	100	2

Window	Rod height (in)	Finish offset (in)	Drop needed (in)	Rod width (in)	Fullness	Total fabric width (in)	Panels (if 50 in wide)